

1/11




Fig. 1

2/11




Fig. 2

3/11




Fig. 3A




Fig. 3B




Fig. 3C




Fig. 3D




Fig. 4A




Fig. 4B

6/11

500

i loop02
_ □ X

View Font Size

Message	Source	Reported by	Summary
Model error	loop02	Simulink	Block diagram 'loop02' contains an algebraic loop. The algebraic loop sol...
Block error	Gain	Simulink	Algebraic loop error with block 'loop02/Subsystem/Gain'
Block error	Gain	Simulink	Algebraic loop error with block 'loop02/Gain'
Block error	Sum	Simulink	Algebraic loop error with block 'loop02/Subsystem/Sum' (algebraic variable)

loop02

Block diagram 'loop02' contains an algebraic loop. The algebraic loop solver is disabled because of the current setting for Algebraic loop optio

530

541

542

Subsystem

Gain

551

552

Sum

Gain

540

550

Open
Help
Close

510

520

Fig. 5A

7/11




Fig. 5B




Fig. 6A







Fig. 6B

10/11



11/11




Fig. 7D